

1. You should have a Windows operating system (Windows 7 or later) running on your PC.
2. Connect a SecuGen fingerprint reader to your PC, and install the [Driver](#) (you must have admin privileges).
3. Download and install one of the following Web API Clients (you must have admin privileges)

It's For both Windows 64 bit and 32 bit machines install